Instructions

Ford A4LD

Oversized Pressure Regulator & Boost Valve Kit

Part No. 56947-06K

- Pressure Regulator Valve
- Small Spring
- Large Spring
- Boost Valve
- Boost Sleeve High Ratio

High Ratio


• O-Rings (2)

Tool Kit

Part No. 56947-TL

- Reamer
- Drill Jig

WARNING: Required tool kit 56947-TL is no longer in production. Check with your distributor for availability.



1. Disassembly

- a. Remove OE valve lineup.
- b. Save OE retainer, washer spring seat, springs and spring seat for reuse.

2. Reaming

Ream pressure regulator bore (for reaming instructions/reamer care, please visit www.sonnax.com). Sonnax reaming tool kit **56947-TL** is required for this operation.

3. Installation & Assembly

- a. Ensure all debris has been removed from valve bore and valve body.
- b. Install OE spring seat onto stem of Sonnax pressure regulator valve.
- c. Install Sonnax pressure regulator/OE spring seat assembly into bore.
- d. Install correct springs:



- If working on a **One-Solenoid** valve body, **Reinstall OE Springs**.
- If working on a **Two-Solenoid** valve body, **Install Sonnax Springs**.
- e. Install OE spring seat washer onto Sonnax boost assembly as shown.
- f. Install Sonnax boost assembly and secure with OE retainer.

4. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg.

