

Instructions

Piston/Damper Repair Sleeve Kit

Part No. BW-DS-1K

- Damper Sleeve
- Damper Rivets (10)


Associated Parts

- GM-O-8V O-Ring
- BW-DA-3P Piston Plate
- **BW-DS-2** Piston/Damper Repair Sleeve (No disassemby required)



Machining & Welding Instructions

- 1. To prepare the piston plate for Sonnax **BW-DS-1** sleeve installation, remove the damper assembly from the piston plate by removing the rivets.
- 2. Chuck the piston plate in a lathe on either the inside or outside diameter (Figure 1).
- 3. Bore the inside diameter to 2.5500-2.5515" to accept the replacement sleeve (Figure 1).
- 4. Remove plate from the lathe and remove all the burrs.



- 5. Insert the sleeve on the damper side, making sure that the sleeve is held firmly against the plate with a clamping fixture (Figure 2, page 2). See how to build a clamping fixture (Figure 3, page 2).
- 6. After the sleeve is welded and cooled, remove the fixture, then lightly clean the inside diameter with 600-grit emery cloth.
- 7. Check for leaks around hub and rivets. Leaks will cause lockup problems and burn the clutch.



PISTON/DAMPER REPAIR SLEEVE KIT BW-DS-1K

Instructions

