

Instructions

6T30/40/45/50 (Gen. 1 & 2), 6T35/31/41/46/51 (Gen. 3 6T40)





- Regulator Valve
- Shuttle Valve
- Spring
- End Plug
- O-Ring




Part No.



- Reamer
- Reamer Jig
- Guide Pin

NOTE: Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX, a self-aligning valve body reaming fixture. More information and instructions can be found online at www.sonnax.com.



1. Disassembly

a. Remove OE retainer and save for reuse.

b. Remove and discard OE valve train.

2. Bore Reaming

Ream TCC regulator bore (for reaming instructions/reamer care, please visit www.sonnax.com). Sonnax reaming tool kit F-144740-TL16 and VB-FIX are required for this operation.

3. Installation & Assembly

a. Be certain all debris has been removed from valve bore and valve body.

- b. Install Sonnax spring.
- c. Install Sonnax regulator valve, ensuring that the Sonnax spring fits inside the spring pocket (as shown).
- d. Install Sonnax shuttle valve and end plug with O-ring.
- e. Reinstall OE retainer.

4. Final Testing

A vacuum test at the port indicated holds 18 in-Hg or more.

