TRANSMISSION PARTS

Instructions

Boost Valve Kit

Part No. 104520-12K

- Valve
- Sleeve
- Spring



1. Disassembly

- a. Remove and discard OE boost valve/sleeve assembly and larger OE spring.
- b. Save OE small spring (not shown) and retainer pin for reuse.

2. Installation & Assembly

- a. Install Sonnax spring, ensuring small OE spring nestles inside.
- b. Install Sonnax boost valve and sleeve.
- c. Reinstall OE retaining pin to secure the boost valve and sleeve in the bore.

3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg.

