

Instructions

Ford 6R80, 280mm (Early), 6R80, 280mm (Late)

Bearing Retainer

Part No. FD-WS-41

1. Disassemble


Remove bearing, stator cap, inner race, springs, rollers, outer race and any loose material on surface of stator (**Figure 1**).

2. Stator Modification

To create a modified pocket and seat for Sonnax bearing retainer turn the stator from $\emptyset 3.670/3.660$ " to the outer diameter ($\emptyset 4.510/4.506$ ") and remove material up to .005" below the bearing surface (**Figure 2**).

3. Assembly

a. Place Sonnax bearing retainer in modified pocket and swedge in place (**Figure 3**).





WARNING: Ensure the top bearing face sits at least .020" above FD-WS-41, when installed in the impeller. No material is allowed above the top surface of FD-WS-41.

b. Reassemble outer race, rollers, springs and inner race.

c. Re-swedge stator cap in place.

SONNAX® TORQUE CONVERTER PARTS

BEARING RETAINER FD-WS-41

Instructions

