

Critical Wear Areas & Vacuum Test Locations

ZIP Drop-In Zip Valve™ Parts Available

A750E-A761E-ZIP Zip Kit® Available


NOTE: OE valves are shown in rest position and should be tested in rest position unless otherwise indicated. Test locations are pointed to with an arrow. Springs are not shown for visual clarity. Low vacuum reading indicates wear and Sonnax parts are noted for replacement.

A750 Series • Lower Valve Body




For specific vacuum test information, refer to individual part instructions included in kits and available at www.sonnax.com.

Click on Sonnax part numbers on page 3 to see more information.




Upper Valve Body



See page 3 for test area IDs, transmission symptoms and recommended repairs.

Upper Valve Body No. 2



Critical Wear Areas & Vacuum Test Locations

ZIP Drop-In Zip Valve™ Parts Available

ZIP KIT A750E-A761E-ZIP Zip Kit® Available

NOTE: OE valves are shown in rest position and should be tested in rest position unless otherwise indicated. Test locations are pointed to with an arrow. Springs are not shown for visual clarity. Low vacuum reading indicates wear and Sonnax parts are noted for replacement.


A760 Series • Lower Valve Body

NOTE: A960 passages are slightly different, however vacuum test locations are the same.




For specific vacuum test information, refer to individual part instructions included in kits and available at www.sonnax.com.

Click on Sonnax part numbers on page 3 to see more information.




Upper Valve Body




See page 3 for test area IDs, transmission symptoms and recommended repairs.

Lower Valve Body No. 2



Upper Valve Body No. 2



Critical Wear Areas & Vacuum Test Locations

Drop-In Zip Valve™
Parts AvailableA750E-A761E-ZIP
Zip Kit® Available

Click on Sonnax part numbers to see more information.

1. Primary Regulator Valve

- Clutch failure
- Soft/Harsh shifts
- Low/High line pressure
- High line pressure in Reverse
- Low line rise
- Low converter pressure
- Overheating

Replace with **Sonnax Part No. 147741-04K** Requires F-147741-TL4 & VB-FIX

2. Boost Assembly

- Clutch failure
- Soft/Harsh shifts
- High line pressure in Reverse
- Low line rise in Drive
- High/Low line pressure
- Overheating
- Low converter pressure

Replace with **Sonnax Part No. 147741-01K**

3. Lockup Relay Valve

- TCC apply & release concerns
- TCC apply codes
- Burnt converter
- Shudder
- Overheating
- Lube failures

Replace with **Sonnax Part No. 147741-07K** Requires F-147741-TL7 & VB-FIX

4. Secondary Regulator Valve

- Harsh lockup
- TCC apply & release concerns
- burnt converter
- Lube failures

Replace with **Sonnax Part No. 147741-10K** Requires F-147741-TL4 & VB-FIX

5. B1 Accumulator Piston

- Delayed engagement
- Flare shifts
- Forward slip
- Burnt clutches

Replace with **Sonnax Part No. 57917E-19K**

6. Solenoid Modulator Valve

- Solenoid performance codes
- Bang shifts
- TCC cycling
- Shift concerns
- Bind-up
- Low control pressure
- TCC slip
- Low cooler flow

7. Clutch Control Valve

- Gear ratio codes
- Solenoid performance codes
- Harsh upshifts/downshifts
- Flare shifts

8. Lockup Control Valve

- TCC apply & release concerns
- TCC codes
- Harsh downshifts
- RPM surge on coast

Replace with **Sonnax Part No. 147741-16K** A750, A761 & A960 Series
Requires F-147741-TL16 & VB-FIX
157740-16K A760 & AB60 Series
Requires F-157740-TL16 & VB-FIX

9. Lockup Control Plunger Valve & Sleeve

- Harsh downshifts
- TCC apply & release concerns
- TCC codes
- Cycling TCC RPM
- Overheated fluid

Replace with **Sonnax Part No. 147741-37K** A750, A761 & A960 Series
157740-37K A760 & AB60 Series

10. Accumulator Control Valve

- Harsh shifts
- Shift codes
- Shift concerns

Replace with **Sonnax Part No. 147741-24K** Requires 147741-TL24

11. Accumulator Control Plunger Valve & Sleeve

- Harsh shifts
- Shift codes
- Shift concerns

Replace with **Sonnax Part No. 147741-43K**

12. Brake Control Valve

- Burnt clutches
- Harsh shifts
- Flare shifts
- Shift concerns

13. B2 Accumulator Pistons

- 5-6 Harsh/Slip
- 32- Harsh
- No engine braking in D2

14. & 15. End Plugs

- Various complaints depending on locations of leaking end plug
- Pressure loss

14. Replace with Sonnax Part No. 147741-30K
15. Replace with Sonnax Part No. 147741-31K

16. SLT Damper

- Harsh/Soft shifts
- Loss of pressure control


17. 1-2 Shift Valve**18. 2-3 Shift Valve****19. 3-4 Shift Valve****20. 4-5 Shift Valve****21. Clutch Apply Control Valve****22. Sequence Valve****23. Clutch Lock Valve****24. B1 Apply Control Valve & Assembly****25. Coast Brake Relay Valve****26. C3 Apply Relay Valve**

- Related shift concerns
- Burnt clutches/brakes


OE Exploded View

A750 Valve Body

NOTE: Depending upon vehicle application, the OE springs shown may not be present.



Upper Valve Body No. 2





A750 Series Valve Body Descriptions

I.D. No.	Description
101	Manual Valve
102	SLT Damper
103	Primary Regulator Valve (inboard) Boost Assembly (outboard)
104	Clutch Control Valve
105	Clutch Apply Control Valve
106	Accumulator Control Valve (inboard) Accumulator Control Plunger Valve & Sleeve (outboard)
107	Sequence Valve
201	Solenoid Modulator Valve
202	Clutch Lock Valve
203	B1 Accumulator Piston
204	Secondary Regulator Valve
205	Lockup Relay Valve
206	Lockup Control Valve (inboard) Lockup Control Plunger Valve & Sleeve (outboard)
207	C3 Check Valve
208	3-4 Shift Valve
209	Brake Control Valve
210	2-3 Shift Valve
211	1-2 Shift Valve
212	B1 Apply Control Valve (inboard) B1 Apply Control Plunger Valve & Sleeve (outboard)
301	Coast Brake Relay Valve

OE Exploded View

A760 Valve Body

NOTE: Depending upon vehicle application, the OE springs shown may not be present.



A760 Series Valve Body Descriptions

I.D. No.	Description
101	Brake Control Valve
102	Accumulator Control Valve (inboard) Accumulator Control Plunger Valve & Sleeve (outboard)
103	SL1 Relay Valve
104	B1 Apply Relay Valve
105	Solenoid Modulator Valve
201	Manual Valve
202	SLT Damper
203	Primary Regulator Valve (inboard) Boost Valve Assembly (outboard)
204	4-5 Shift Valve
301	B2 Accumulator Piston
302	Reverse Sequence Valve
303	Clutch Control Valve
304	Clutch Apply Relay Valve
305	B1 Accumulator Piston
306	Secondary Regulator Valve
307	Lockup Relay Valve
308	Lockup Control Valve (inboard) Lockup Control Plunger Valve & Sleeve (outboard)
309	C3 Check Valve
310	1-2 Shift Valve
311	B4 Check Valve
312	2-3 Shift Valve
313	3-4 Shift Valve
314	B2 Accumulator Piston
401	C3 Apply Relay Valve