

Oversized Neutral Control Valve Kit

Part No.
122892-13K

- Valve
- End Plug

NOTE: Found in Jaguar, Land Rover, Mazda and VW.

Tool Kit


Part No.
F-122892-TL13

- Reamer
- Reamer Jig
- Guide Pin

NOTE: Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX, a self-aligning valve body reaming fixture. More information and instructions can be found online at www.sonnax.com.



Jatco JF506E; VW/Audi 09A



1. Disassembly

- Remove OE valve train, saving the roll pin and spring for reuse.
- Discard OE end plug and valve.

2. Bore Reaming

Ream neutral control bore (for reaming instructions/reamer care, please visit www.sonnax.com). Sonnax reaming tool kit F-122892-TL13 and VB-FIX are required for this operation.

3. Installation & Assembly

- Be certain all debris has been removed from the valve bore and valve body.
- Install Sonnax oversized valve and reinstall OE spring.
- Install Sonnax end plug and reinstall OE roll pin.

4. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg.

