Instructions

Chrysler 32RH, 42RE, 42RH, 46RE, 46RH, 47RE, 47RH, 48RE, A727, A904

Oversized Throttle Valve Kit

Part No. 22771-04K

- Valve
- Plunger
- Sleeve
- Spring Shims (3)*

• TV Spring Orange
• Alternative TV Spring* Purple

* Performance Use Only


NOTE: Fits all Chrysler RWD models, including '05-later units with motorized linkage.

Tool Kit

Part No.

- Reamer
- Reamer Jig
- Guide Pin

NOTE: Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX, a self-aligning valve body reaming fixture. More information and instructions can be found online at www.sonnax.com.



1. Disassembly

Remove OE throttle valve train. Set aside retainer for reuse; discard other parts.

2. Bore Reaming

Ream throttle valve bore (for reaming instructions/reamer care, please visit www.sonnax.com). Sonnax reaming tool kit **F-22771-TL** and **VB-FIX** are required for this operation.

3. Installation & Assembly

- a. Be certain all debris has been removed from the valve bore and valve body.
- b. Install Sonnax throttle valve, spring shims (*if desired, see chart below), one of two throttle valve springs, plunger and sleeve.
- c. Secure valve train with OE retainer.

4. Adjust TV Stop

Using available Chrysler gauge or equivalent, set stop distance between throttle lever and throttle plunger to .627". To obtain correct distance, throttle valve must be fully bottomed and throttle valve spring fully compressed. With gauge in place, valve train should have no movement.

- 28 psi

Customizing TV Pressure for Performance Applications Shims can be installed on TV valve stem to customize shift points Spring/Shim Selection Approx. Change to TV Pressure Use of 3 shims is NOT recommended Sonnax Throttle Spring + 2 Shims + 14 psi Sonnax Throttle Spring + 1 Shim + 7 psi Sonnax Alternative TV Spring + 3 Shims - 7 psi Sonnax Alternative TV Spring + 2 Shims - 14 psi Sonnax Alternative TV Spring + 1 Shim - 21 psi

Sonnax Alternative TV Spring ONLY

