

Heavy Duty Kickdown Band Strut

Part No.
22825-01

Chrysler 46RE, 46RH, 47RE, 47RH, 48RE, A727



1. Disassembly

- Remove pan and valve body to expose bottom of the transmission.
- Remove adjusting screw from the band.
- Remove OE strut.

2. Installation & Assembly

- Insert Sonnax strut with the flat surface facing away from the band (**Figure 1**).
- Replace OE adjusting screw and set to manufacturer's standards.

