SONDAX PERFORMANCE HIGH PERFORMANCE TRANSMISSION PARTS

Instructions

GM Powerglide





Before installing servo, inspect OE servo bore and remove any burrs or sharp edges. Take special notice of the corner at intersection of feed hole and any scratches in bore diameter.

