Instructions

Ford AOD

Governor Circuit End Plug Kit

Part No. 76999-05K


• 3-4 Shift Valve

• 3-4 Shift Sleeve

• End Plugs (2) Medium

End PlugO-Rings (8)Small4 Extra

NOTE: Fits mid '83-later.



1. Wet Air Test Verification Before and/or After Installation

The most effective method is with the valve body assembled to the case, then wet air tested through the output shaft governor feed holes.

2. Disassembly

- a. If OE valve is not going to be removed, hold/wedge valve inward with small flat blade screwdriver to keep the valve in place.
- b. Remove OE retaining clip and save for reuse.
- c. Remove OE end plug from the valve body and discard.
- d. Remove OE 3-4 shift valve and discard.

3. Assembly

Valve & Sleeve:

Install Sonnax 3-4 shift valve and sleeve and secure with OE retaining clip.

End Plugs:

- a. Install Sonnax O-rings into outer groove of Sonnax end plugs and lubricate.
- b. With threaded hole facing out, rotate the end plug during installation and push into valve body bore just enough to replace the OE retaining clip.



NOTE: The 8-32 UNC threaded hole may be used to assist in end plug installation and removal.