

### Oversized 3-4 Accumulator Valve Kits

**Part No.**

**84754-58K**

- Valve
- Spring



**NOTE:** Fits Volvo units only.


### Tool Kit

**Part No.**

**F-84754-TL55**

- Reamer
- Reamer Jig
- Guide Pin

**NOTE:** Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX, a self-aligning valve body reaming fixture. More information and instructions can be found online at [www.sonnax.com](http://www.sonnax.com).



#### 1. Disassembly

- Remove OE 2-3 accumulator sleeve/valve assembly and retain for reuse.
- Remove and discard OE 3-4 accumulator valve and spring.

#### 2. Bore Reaming

Ream accumulator bore (for reaming instructions/reamer care, please visit [www.sonnax.com](http://www.sonnax.com)). Sonnax reaming tool kit **F-84754-TL55** and **VB-FIX** are required for this operation.

#### 3. Installation & Assembly

- Place Sonnax spring into spring pocket of Sonnax valve.
- Install spring and valve into reamed bore, spring end first.
- Reinstall OE 2-3 accumulator sleeve/valve assembly and secure with OE retainer.

#### 4. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in.-Hg.

