

## Boost Valve Kit

### Part No.

**94987-09K**

- Valve
- Sleeve

**NOTE:** This kit fits '98-later models: Isuzu NPR, GMC Forward Tiltmaster, Chevrolet Forward, Nissan UD and Mitsubishi Fuso trucks.

## Aisin AW 450-43LE



**NOTE:** The pressure regulator bore also is subject to extreme wear and should be vacuum tested at the port indicated (**Figure 1**). If the port fails to hold at least 14 in-Hg of vacuum, then the pressure regulator valve must be repaired to re-establish proper pressures.

### 1. Disassembly

- Remove OE retainer and save for reuse.
- Remove and discard OE sleeve and valve.

### 2. Installation

- Be certain all debris has been removed from the valve bore and valve body.
- Install Sonnax main boost valve assembly.
- Secure with OE retainer.

### 3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 14 in-Hg.

