

### Instructions

# Honda/Acura 4-Speed, 3-Shaft, 5-Speed



#### 1. Disassembly

- a. Remove OE retainer, set aside for reuse.
- b. Remove and discard OE end plug.

#### 2. Installation & Assembly

a. Insert Sonnax end plug with tapped hole outboard, using light taps with a dead-blow hammer.

b. Install just far enough to insert OE retaining clip.

## **End Plug**



• End Plug

NOTE: Fits all units with dual linear solenoids.

Some BMXA units have been found with plugs which have smaller diameter clip-grooves and narrower retainers as shown below. Sonnax end plugs will not work in these applications (Figure 1).



NOTE: Due to application variations, additional end plugs may be required. Single end plugs in all three sizes (12mm, 14mm, 15mm) are available separately. Check the Sonnax website for part numbers available through your distributor.