

## Oversized Pressure Regulator & Boost Valve Kit

### Part No. 37740-03K


- Pressure Regulator Valve
- Boost Valve
- Boost Sleeve
- Shims (2)

# Tool Kit Part No. F-37740-TL3

- Reamer
- Reamer Jig
- Guide Pin

**NOTE:** Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX, a self-aligning valve body reaming fixture. More information and instructions can be found online at www.sonnax.com.

### Toyota/Lexus U341E, U341F





**CAUTION:** Before disassembly, note which notch on the OE sleeve holds the retaining pin. This will be necessary for proper reassembly.

#### 1. Disassembly

- a. After noting which sleeve notch holds retaining pin (see caution above), remove OE retaining pin and set aside for reuse.
- b. Remove and discard OE valve stop.
- c. Remove OE boost valve/sleeve assembly. Set aside sleeve, to be measured before reassembly.
- d. Remove OE spring and spring seat washer; set aside for reuse.
- e. Remove and discard OE pressure regulator valve.

#### 2. Bore Reaming

Ream pressure regulator bore (for reaming instructions/reamer care, please visit www.sonnax.com). Sonnax reaming tool kit **F-37740-TL3** and **VB-FIX** are required for this operation.



#### TRANSMISSION PARTS

OVERSIZED PRESSURE REGULATOR & BOOST VALVE KIT 37740-03K, F-37740-TL3

Instructions

#### 3. Installation & Assembly

- a. Ensure valve bore and body are clean and cleared of all debris.
- b. Measure from open end of OE sleeve to notch that held retaining pin (**Figure 1**). Compare measurement to chart to determine correct amount of Sonnax shims to install, if any (**Figure 2**).
- c. Place OE spring seat washer and appropriate Sonnax shim(s) on Sonnax pressure regulator valve stem and install into bore.
- d. Reinstall OE spring.
- e. Install Sonnax boost valve/sleeve assembly. Secure with OE retaining pin, ensuring pin is pushed thru retaining pin hole in replacement sleeve.

#### 4. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 16 in-Hg.




Figure 2

OE Sleeve Measurement	Install
1.715"	OE spring seat washer, 0 Sonnax shims
1.755"	OE spring seat washer with 1 Sonnax shim
1.795"	OE spring seat washer with 1 Sonnax shim
1.835"	OE spring seat washer with 2 Sonnax shims
1.875"	OE spring seat washer with 2 Sonnax shims

