


## Remanufactured Solenoid Block

Part No.

**132420-A**

## Chrysler 62TE



**NOTE:** Ensure that range sensor (TRS) wiring is in place (**Figure 1**), as it may have dislodged during shipping. Incorrect wire routing can cause damage to wiring during installation.

1. Install mounting bolts and tighten to 6 Nm (50 in-lb).
2. Make electrical connections to three connectors (**Figures 1 & 2**).

