

1-2 Accumulator Piston Cover Kit

Part No.

35988-01K

- Cover
- O-Rings (2)

GM 350, 350C



1. Place both Sonnax O-rings back-to-back onto cover.
2. Lubricate O-rings and case bore with assembly lube.
3. Carefully work Sonnax cover into position.
4. Push in on cover and install OE retaining ring.
5. Verify OE retaining ring is fully seated into its groove.