Instructions

### **Ford 6R140**

### Oversized Direct Clutch Regulator Valve Kit

### Part No. 126740-11K

- Valve
- Spring


### **Tool Kit**

# FIXTUF

## Part No. F-126740-TL11

- Reamer
- Reamer Jig
- Guide Pin

**NOTE:** Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX, a self-aligning valve body reaming fixture. More information and instructions can be found online at www.sonnax.com.



### 1. Disassembly

- a. Remove OE retainer and end plug, set aside for reuse.
- b. Remove and discard OE valve and spring.

### 2. Bore Reaming


Ream direct clutch regulator bore (for reaming instructions/reamer care, please visit www.sonnax.com). Sonnax reaming tool kit **F-126740-TL11** and **VB-FIX** are required for this operation.

#### 3. Installation & Assembly

- a. Place Sonnax spring into bore, followed by Sonnax valve. Ensure spring seats over valve spring guide.
- b. Reinstall OE end plug and secure with OE retainer.

### 4. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 16 in-Hg.



©2015 Sonnax Industries, Inc. 126740-11K-IN 03-20-15