

## Ford C6

### Pilot

#### Part No.

**FD-PI-8**

**NOTE:** Use this 1.848" pilot to convert Sonnax performance converter kit FD-RK-4 for use in 1960s' big-block applications.



1. On the front cover **FD-CC-5**, remove the diameter that is used to pilot the smaller 1.375" dia. pilots.
2. Press the 1.848" dia. pilot onto the piloting diameter.
3. Tack weld the pilot into place. The front cover is now ready to be assembled with the rest of the converter components.

