TORQUE CONVERTER PARTS

Instructions

## **Stator Adapter**

# Part No. GM-WA-3

#### **Applications**

Convert early-style GM TH400 stator to late-style

#### **Associated Parts**

- **GM-N-8HLT** Thrust Bearing
- GM-90-10G Flanged Impeller Hub



#### 1. Installation Instructions

- a. Sonnax stator adapter **GM-WA-3** is not a drop in replacement.
- b. Machine a step into the stator (Figure 1) to accept the GM-WA-3 stator adapter. The stack height of the stator with bearing installed is unchanged from old to new configuration.



**NOTE:** Care should be taken to keep O.D. and thrust surface true to the axis of the stator. The adapter should press onto the stator with a .011–.033" press fit.

### 2. Impeller Hub Requirements

The OE impeller hub does not have a flat back-up surface on which to seat Sonnax thrust bearing **GM-N-8HLT**. Install Sonnax flanged impeller hub **GM-90-10G** to create this surface.

