TORQUE CONVERTER PARTS

Instructions

## Honda/ACURA B7TA, B7VA, B7YA

## **Impeller Hub**

Part No. HO-90-4G

## **Associated Parts**

- HO-O-1V O-Ring
- HO-O-2V O-Ring
- JA-N-13 Thrust Bearing



## Modify the Stator Bore to Accept JA-N-13 Thrust Bearing:

- 1. Measure the JA-N-13 bearing O.D.
- 2. Add .002" to that measurement.
- 3. Bore out the opening on the stator to the calculated dimension (**Figure 1**) to allow the bearing to fit into the pocket of the stator (**Figure 2**).
- 4. Be sure to continue the machining process to the bottom of the bore to provide plenty of lube oil for good bearing life.

**NOTE:** Stator bore modification is required when installing impeller hub **HO-90-4G** and using the recommended enclosed thrust bearing **JA-N-13** in place of the open bearing.



