

Servo Piston & Cover Kit

Part No.

28821-05K

- Cover Purple Anodized
- Pipe Plug
- Hex Head Bolts (3)
- Cover O-Ring
- Cover Gasket PTFE
- Piston Seal Rings (2)
- Piston



Before installing servo, inspect OE servo bore and remove any burrs or sharp edges. Take special notice of the corner at intersection of feedhole and any scratches in bore diameter.

