

Boost Valve Kit

Boost Valve & Sleeve Assembly


84754-30K

Patent No. 6.832.632

Part No.

Instructions

GM 4T65-E



1. Disassembly


- a. Remove and discard OE boost valve and sleeve assembly.
- b. Remove OE retaining clip, small and large springs and pressure regulator valve and save for reuse.

2. Installation & Assembly

- a. Be certain all debris has been removed from the valve bore and valve body.
- b. Reinstall OE pressure regulator valve, large spring and small spring.
- c. Install Sonnax boost valve and sleeve assembly and secure with OE retaining clip.

3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg.



©2020 Sonnax Transmission Company, Inc. • A Marmon / Berkshire Hathaway Company

84754-30K-IN 01-08-20

800-843-2600 • 802-463-9722 • F: 802-463-4059 • www.sonnax.com