


Instructions


GM 4T60-E, 4T65-E


3-2 Manual Downshift Valve

Part No. 84754-37K

NOTE: Fits '94–later units only. Not for use in 4T65-E Geartronic[®] or Tapshift[®] units.







1. Disassembly

- a. Remove OE 3-2 manual downshift valve bore lineup and discard 3-2 manual downshift valve.
- b. Retain OE 2-3 shift valve, spring, end plug and retainer for reuse.


NOTE: If OE 2-3 shift valve shows signs of wear, replace with Sonnax 84754-36K.


2. Installation & Assembly

- a. Identify valve body as a '94-later (Figures 1, 2 & 3) as Sonnax valve will not fit earlier models.
- b. Reinstall OE or Sonnax 2-3 shift valve as shown (main photo).
- c. Install Sonnax 3-2 manual downshift valve.
- d. Reinstall OE spring, end plug and retainer.

3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg (**Figure 4**).





©2020 Sonnax Transmission Company, Inc. • A Marmon/Berkshire Hathaway Company

800-843-2600 • 802-463-9722 • F: 802-463-4059 • www.sonnax.com