

## Clutch A & E Control Boost Valve Kit

### Part No.


# 95740-28K

- Valves (2)
- Sleeves (2)

**NOTE:** Services two bores.

Kit is not compatible with ZF6HP19/26/32 (Gen. 1) units. To differentiate between Gen. 1 and Gen. 2 valve bodies, refer to ZF Identification Guide at [www.sonnax.com](http://www.sonnax.com).

## ZF6HP21/28/34 (Gen. 2)



### 1. Disassembly

- Remove OE retaining clips and end plugs and save for reuse.
- Remove and discard OE boost valves and sleeves.

### 2. Installation & Assembly

- Install the Sonnax boost sleeves and valves.
- Install the OE end plug, followed by the OE retaining clip.

### 3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg.

