

TCC Accumulator

NOTE: Does not fit '19-later 68RFE.

Spring


Part No.

• Springs (5)

44912-01

Instructions

Chrysler 45RFE, 545RFE, 65RFE, 66RFE, 68RFE



1. Disassembly

- a. Remove OE accumulator retainer, spring and valve.
- b. Discard spring, while keeping valve and retainer for reuse.
- c. Ensure all broken spring pieces are removed.

2. Installation & Assembly

- a. Inspect valve and bore for wear or damage from broken spring.
- b. Insert Sonnax spring into valve and install into accumulator bore.
- c. Secure with OE valve retainer.

800-843-2600 • 802-463-9722 • F: 802-463-4059 • www.sonnax.com