

Direct/Input/High & Low Reverse Clutch Solenoid

Part No.

63425

NOTE: Also fits Hyundai/Kia A5SR1/2.

Jatco/Nissan RE5R05A



NOTE: Solenoids may be difficult to remove from valve body. Carefully twisting a flat-blade screwdriver between retainer bracket and valve body can ease solenoid removal. Alternately, a punch inserted from bottom of channel plate can be used to lightly tap solenoid snout outward.

1. Disassembly

Remove OE solenoid from direct clutch, input clutch or high & low reverse clutch location (**Figure 1**).

2. Installation & Assembly

- Lubricate O-rings on Sonnax replacement solenoid; install and secure solenoid into proper location (**Figure 1**).
- After solenoid replacement, reset TCM keep-alive memory (KAM) and shift adaptations according to OE specification.

