

Clutch Control Valve Spring


Part No.

99740B-01

Springs (2)

NOTE: Fits Mitsubishi and Isuzu versions only. See valve body identification information below.

Aisin Seiki AS68RC



1. Disassembly

- Remove OE solenoid bracket and bolt, and two Solenoids. Save for reuse.
- Remove OE plunger valves. Save for reuse.
- Remove and discard OE clutch control valve springs.

2. Installation & Assembly

- Install Sonnax springs into bores.
- Reinstall OE plunger valves, ensuring spring stem slides through springs.
- Reinstall solenoids, solenoid bracket and bolt.

AS68RC Valve Body Identification:

