


# **Pressure Regulator Isolator Valve Kit**

## Part No. 144510-15K

- Valve
- Sleeve



#### 1. Disassembly

- a. Remove OE retainer pin and keep for reuse.
- b. Remove OE pressure regulator isolator valve and sleeve assembly and discard.

### 2. Installation & Assembly

- a. Clean the bore thoroughly.
- b. Install Sonnax pressure regulator isolator valve and sleeve.
- c. Reinstall OE retainer pin.

#### 3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg.

