


# ETRS Mode 2 Boost Valve Kit

## Part No. 184740-06K

- Valve
- Sleeve



### 1. Disassembly

- a. Remove OE retainer and save for reuse.
- b. Remove and discard worn ETRS mode 2 OE boost valve and sleeve.

#### 2. Installation & Assembly

- a. Ensure all debris has been removed from valve bore and body.
- b. Install Sonnax ETRS mode 2 boost valve and sleeve as shown.
- c. Reinstall the OE retainer.

#### 3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 16 in-Hg.

