Instructions

Signal Damper Piston Kit


Part No. 184740-01K

- Pistons (4)
- Sleeves (4)
- O-Rings (5)

1 Extra

• Springs (4)

Patent No. 11,933,326



1. Disassembly

Remove and discard the OE damper piston and spring.

2. Installation & Assembly

- a. Be certain all debris has been removed from the valve bore and valve body.
- b. Install O-ring into sleeve O-ring groove, roll O-ringed sleeve on bench to size O-ring into groove. Lubricate O-ring with Sonnax Slippery Stick **O-LUBE**.
- c. Install spring into the piston/sleeve assembly.
- d. Install piston/sleeve assembly with O-ring and spring into the bore.

3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg.

