Instructions

1-2 Accumulator Spring Kit


Part No.

76948-10**K**

Inboard Spring GreenOutboard Spring Yellow

NOTE: Fits '01-later. Only use the two springs included in this kit. Some OE applications have a blue inner spring that is NOT used with this kit.

OE Part Nos. 1L3Z-7F284-AA & 1W7Z-7F284-AA



1. Installation & Assembly

- a. Be certain all debris has been removed from the bore.
- b. Visually instpect the quality of the seals on the OE accumulator piston, if necessary replace the accumulator piston.
- c. Install Sonnax green spring into the inboard end of the 1-2 accumulator piston and install the piston and spring into the case.
- d. Install Sonnax yellow spring into the outboard end of the 1-2 accumulator piston, followed by the accumulator cap and snap ring.