

Oversized Secondary Pulley Control Valve Kit

TRANSMISSION PARTS

Part No. 113741-17K

- Valve
- End Plug

Tool Kit


Part No. F-113741-TL17

- Reamers (2)
- Reamer Jig
- Guide Pin

NOTE: Tool kit for 113741-17K can also be used for 113741-19K

NOTE: Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX, a self-aligning valve body reaming fixture. More information and instructions can be found online at www.sonnax.com.

Jatco/Nissan JF010E (RE0F09A/RE0F09B)



1. Disassembly

- a. Remove OE retainer, save for reuse.
- b. Remove and discard OE end plug.
- c. Remove OE spring, save for reuse.
- d. Remove and discard OE valve.

2. Bore Reaming

NOTE: Tool kit F-113741-TL17 contains two reamers. For JF010E valve bodies use reamer F-113741-RM17 ONLY.

Ream secondary pulley control valve bore (for reaming instructions/reamer care, please visit www.sonnax.com). Sonnax reaming tool kit **F-113741-RM17** and **VB-FIX** are required for this operation.

3. Installation & Assembly

- a. Ensure all debris has been removed from valve bore and body.
- b. Install Sonnax secondary pulley control valve.
- c. Reinstall OE spring.

- d. Install Sonnax end plug.
- e. Reinstall OE retaining clip.

4. Final Testing

Vacuum testing at the port indicated holds the recommended minimum 16 in-Hg.

