


## Pressure Regulator Valve

Part No.

**28999-03**

## GM Powerglide



### 1. Disassembly

- Remove OE retaining clip, boost valve assembly, spring cup, spring, and pressure regulator valve assembly from bore.
- Remove OE spring seat clip from pressure regulator valve and keep for reuse.
- Discard OE pressure regulator valve, keep all other parts for reuse.

### 2. Installation & Assembly

- Press OE spring seat clip onto stem of Sonnax pressure regulator valve.
- Slide Sonnax pressure regulator valve into the bottom of the valve body bore.
- Return OE spring, spring cup and boost valve assembly to the bore, and retain with the OE retaining clip.