

Line Pressure Solenoid A & B

Part No.
33431G

NOTE: TCC Solenoid **33425G** is also available from Sonnax. See **Figure 1** for correct locations.

Jatco/Nissan JF010E (RE0F09A/RE0F09B)



1. Disassembly

Remove OE line pressure solenoid A or B (**Figure 1**).

2. Installation & Assembly

- Lubricate O-rings on Sonnax replacement solenoid; install and secure solenoid into proper location (**Figure 1**).
- After solenoid replacement, reset TCM keep-alive memory (KAM) and shift adaptations according to OE specification.

