


# **Reverse Boost Valve Kit**

# Part No. 47740-17K

- Valve
- Sleeve



## 1. Disassembly

- a. Remove and discard the worn OE Reverse boost assembly.
- b. Save OE retainer for reuse.

### 2. Installation & Assembly

- a. Install the Sonnax Reverse boost valve and sleeve as shown.
- b. Replace the OE retainer, in location shown, to secure assembly in the bore.

### 3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg.

