

### HIGH PERFORMANCE TORQUE CONVERTER PARTS

Instructions

## GM Powerglide, 350, 400, 10"

## 10" Performance Converter Mounting Ring Kit

# Part No. GM-RK-1417

• Impeller Hub

Butt-mount

• Turbine Hub


17-Tooth

- Conversion Pilot
- Front Cover Bushing
- Mounting Ring with 10¾" and 11½" bolt patterns
- Thrust Washer
- Countersunk Bolts (3)

NOTE: When using in a
Powerglide application the impeller hub must mount .070" taller. Either leave a .070" boss on the impeller to extend the height when using the impeller hub included in the kits or use a GM-90-300G impeller hub and cut it down to 3.695" length.



- 1. Use an OE GM 245mm front cover from a front-wheel-drive application. If needed, take a skim cut off the OE mounting pads of the front cover.
- 2. Apply Loctite® to the three mounting bolts (MI-FN-3). Bolt Sonnax mounting ring (GM-BM-4) to the front cover (Figure 1).
- 3. Mount cover assembly into a lathe using the mounting ring bolt holes to fixture. Using the outer diameter of the cover as a reference, bore a 2.031 2.036" hole to remove the OE pilot. Face off the inside surface (just outside the 2.031 2.036" hole) so that it is .750" from the face of the mounting ring (**Figure 2**).





### HIGH PERFORMANCE TORQUE CONVERTER PARTS

10" PERFORMANCE CONVERTER MOUNTING RING KIT GM-RK-1417

Instructions



**NOTE:** Cover will sit deeper into impeller than it did on OE application.

- 4. Turn the mating lip of the cover down to 2.00" from the mounting pads and turn a 15° chamfer, .100" deep on the inside lip. Machine outside diameter of lip to 9.938" (**Figure 2**).
- 5. Remove cover assembly from lathe. The pilot will install from inside of the cover. Weld around inside seam and then around outside seam (**Figure 3**).
- 6. Install Sonnax front cover bushing (CH-B-2-CP) (Figure 4).
- 7. Mount turbine into the lathe. Remove OE turbine hub and bore the turbine out to 2.350 2.355".
- 8. Install Sonnax turbine hub from cover side of the turbine. Weld cover side seam (**Figure 5**).
- 9. Continue assembly per normal shop procedure. Suggested endplay is between .005" and .010".

